



system VEGAS

V-39



INSTRUKCJA MONTAŻU

Narzędzia potrzebne do montażu




UWAGA !!

MONTOWANIE USZKODZONYCH
ELEMENTÓW POWODUJE UTRATĘ
GWARANCJI

nr	D[mm]	S[mm]	G[mm]	Ilość
1	550	407	48	1
2	955	542	48	1
3	955	542	48	1
4	550	407	48	1
5	1790	405	48	1
6	1790	540	48	1
7	1790	405	16	4
8	1790	400	16	1


nr	D[mm]	S[mm]	G[mm]	Ilość
9	922	400	16	1
10	922	80	16	1
11	1815	475	2,5	2
12	1815	370	2,5	2
13	1782	495	16	1
14	1782	495	16	1
15	532	320	16	4

lewa




lub

prawa




W przypadku reklamacji proszę o podanie numeru pakowacza znajdującego się na kartonie



A - 2 St.




I - 4 St.



R - 10 St.
4 x 60 mm




M - 1 St.




T - 2 St.



F - 6 St.



H - 2 St.




N - 4 St.
4 x 30 mm




U - 2 St.



G - 40 St.
3,5 x 16 mm




L - 30 St.




W - 4 St.



E - 100 St.



C - 8 St.



D - 4 St.




S - 6 St.




P - 20 St.




B - 20 St.



K - 18 St.




Z - 1 St.






J - 4 St.

I





II





IV



V

